







## SPITFIRE MK IIA

- 1 Cut out all of the parts carefully.
- Check that they align when placed back-to-back. 2
- Glue the backs of the upper and lower wings and carefully stick together. m
- Cut the slit in the centre of the wings from the top 4
- Glue the insides of the fuselage leaving the flaps without glue.

S

- Stick the side together and cut the slits in the tail and upper nose. 9
- Carefully hold the flaps together and put through the slit on the top of the wings.
- Bend the flaps out and glue to the lower side of each wing. They may need held until stuck firmly.  $\infty$
- Glue the upper and lower elevator pieces together, cut out the slit and slip the elevator into the slit in 0
- Glue both sides of the propeller together, cut the slit and slip into the slit on the nose. 10
- Finish off by sticking the Flap Cover under the wings.
- You could add authenticity by twisting each propeller very slightly.